

Floor Tape & Symbol Application Instructions

- Surface must be completely dry.
- Surface must be clean and free of any contaminants which may include but not limited to oils, grease, sand, dirt, dust, loose aggregate, curing compound, mud, soil and salt.
- Do not apply product directly on seams, joints, deteriorating marking or substrates.
- Tapes applied directly over seams and joints must be cut through 1" on both sides of the joints or seams to prevent de-bonding of the tape.
- Do not overlap tape, use butt splices
- Firmly tamp the product in the same direction as it was applied on the initial pass. A minimum of three passes total. Use a tamper device with a minimum 150 lb. (90kg) load and a tamping surface a minimum 2" wider than the width of tape being applied. Never twist the tamping device during tamping. Repeat tamping as necessary to insure tape has completely confirmed to the surface.
- All users should test a small piece of product for satisfactory adhesion prior to installing large portions.

*If removal is required, place a small scraper blade underneath tape and pull in an upward direction at a 180° angle. If tape has not been damaged, material will be removable in tact or in large pieces.

*For best adhesion and conformability, please do not expose tape to cold temperatures until the moment of installation.

